


СХЕМЫ РАЗМЕРОВ

SWB-04-18



	SWB -04	SWB -06	SWB -09	SWB -12	SWB- 15	SWB -18
A	180		180		197	
A1		242		242		259
B	268	268	290	290	330	330
C	788	788	886	886	1080	1080
D	58	58	58	58	58	58
E	672	672	770	770	964	964
F	90		100		120	